


J11	J12	Vu [dB]
open	open	50
short	open	62.5
open	short	65
short	short	69

	J5	J8	J9
Servo Amp On	short	1-2	short
Servo Amp Off / DC Coupling	short	2-3	open
Servo Amp Off / AC Coupling	open	2-3	open



Title		
OPpp1 - Output Stage with Servo Amp		
Size	Number	Revision
A4	RStA0025.1	0
Date:	15.11.2011	Sheet of
File:	C:\User\Layout\RStA0025\OPpp1.out.SchDoDrawn By: Ralph Stens	